

Quick Reference

| | |
|-------------------------|--|
| Scheduled Maintenance | <i>Initial: 100 miles (150 km)</i> <i>Regular: every 600 miles (1,000 km)</i> |
| Pre-ride Inspection | Check the following items each time before you ride (page 43): engine oil, fuel, tires, nuts & bolts, underbody & exhaust system, air cleaner housing drain tube, leaks, loose parts, cables, lights, throttle, brakes, switches, steering. |
| Fuel/Capacity | unleaded gasoline, pump octane number 86 or higher 3.67 US gal (13.9 l) reserve: 0.82 US gal (3.1 l) |
| Engine Oil | API Service Classification SG or higher except oils labeled as energy conserving on the circular API service label, SAE 10W-40, JASO T 903 standard MA, Pro Honda GN4 or HP4 (without molybdenum additives) 4-stroke oil or equivalent |
| Maximum Weight Capacity | 463 lbs (210 kg) rider, all cargo and accessories |