

Maintenance Schedule

ITEMS		FREQUENCY	WHICHEVER COMES FIRST		INITIAL MAINT.	REGULAR MAINT. INTERVAL		Refer to page
			↔	mi	100	600	1200	
				km	150	1000	2000	
NOTE	HOURS	20	100	200				
NON EMISSION RELATED ITEMS		DRIVE CHAIN	NOTE 1,2		I,L	(I,LEVERY 300mi (500km) or 50 operating hours)		133
		DRIVE CHAIN SLIDER						133
	*	BRAKE FLUID	NOTE 3					115
	*	BRAKE PAD WEAR	NOTE 1,2					119
		BRAKE SYSTEM						115
		SKID PLATES, ENGINE GUARD						130
	*	CLUTCH SYSTEM						100
	*	SUSPENSION						109
	*	SPARK ARRESTER				C	C	131
	*	NUTS, BOLTS, FASTENERS						-
	**	WHEELS/TIRES						123,165
	**	STEERING SHAFT HOLDER BEARINGS						-
	**	STEERING SYSTEM						-

* Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official Honda Service Manual (page 188).

** In the interest of safety, we recommend these items be serviced only by your Honda dealer.