

Maintenance Schedule

ITEMS	FREQUENCY	WHICHEVER COMES FIRST ⇔ NOTE	INITIAL MAINT.		REGULAR MAINT. INTERVAL		Refer to page
			km	150	1000	2000	
			mi	100	600	1200	
		HOURS	20	100	200		
DRIVE CHAIN		NOTE 1,2		I, L	(I, L EVERY 500km (300mi) or 50 operating hours)		141
DRIVE CHAIN SLIDER							141
* BRAKE FLUID		NOTE 3					124
* BRAKE PAD WEAR		NOTE 1,2					128
* BRAKE LIGHT SWITCH							130
BRAKE SYSTEM							124
* REVERSE LOCK SYSTEM							109
SKID PLATES, ENGINE GUARD							140
* CLUTCH SYSTEM							105
* SUSPENSION							118
* SPARK ARRESTER					C	C	116
* NUTS, BOLTS, FASTENERS							—
** WHEELS/TYRES							—
** STEERING SHAFT HOLDER BEARINGS							—
** STEERING SYSTEM							—

- * Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official Honda Shop Manual.
- ** In the interest of safety, we recommend these items be serviced only by your Honda dealer.