

| | |
|-----------------------------------|-----|
| Cleaning..... | 143 |
| Climbing hills | 69 |
| Clutch adjustment..... | 110 |
| <i>Consumer information</i> | 151 |
| Crossing slopes..... | 78 |
| Customer service | 153 |

D

| | |
|-----------------------|---------|
| Differential oil..... | 107 |
| Dimmer switch..... | 21 |
| Dipstick | 31, 101 |
| Driveshaft boots..... | 138 |

E

| | |
|--|---------|
| Emission control system | 151 |
| Engine | |
| Idle speed adjustment..... | 98 |
| Break-in procedures..... | ii |
| Flooded engine..... | 62 |
| Starting the engine..... | 59 |
| Engine guard and skid plates | 135 |
| Engine oil | |
| Changing oil..... | 103 |
| Checking oil level and adding oil..... | 101 |
| Oil filler cap/dipstick..... | 31, 101 |
| Oil filter | 103 |
| Oil high temperature indicator lamp..... | 21 |
| Recommendations | 102 |
| Engine stop switch..... | 15 |
| Exhaust system | |
| Cleaning..... | 39 |
| Purging..... | 136 |