

Instruments & Controls

This section shows the location of all indicators and controls you would normally use before or while riding your ATV.

The items listed on this page are described in this section. Instructions for other components are presented in other sections of this manual where they will be most useful.

Operation Component Locations	17
Indicators & Displays	20
Multi-function Display	26
Speed and Mileage Unit Changing	29
4WD Indicator	29
Gear Position Indicator	30
Fuel Gauge	31
Digital Clock	33
Odometer	34
Tripmeter	34
Coolant Temperature Gauge	35
Hourmeter	37
Maintenance Tripmeter & Maintenance Hourmeter	38

(cont'd)