



# Indicators & Displays

7	Mode button	Selects display in the lower parts of multi-function display (page 26). This button also used to change the speed and mileage unit (page 29), adjusts the clock (page 33) and resets tripmeter, maintenance tripmeter and maintenance hourmeter (page 38).
---	-------------	--

