





Storing Your Honda

Preparation for Storage

Refer to Safety Precautions on page 113.

- 1. Change the engine oil and filter (page 137).
- 2. Make sure the cooling system is filled with a 50/50 % antifreeze solution (page 145).
- 3. Fill the fuel tank. Make sure the fuel fill cap is properly installed.









