



Table of Contents

BEFORE RIDING (cont'd)

| | |
|-----------------------------------|----|
| Load Limits & Guidelines | 49 |
| Loading | 49 |
| Load Limits | 50 |
| Loading Guidelines | 51 |
| Accessories & Modifications | 52 |
| Accessories..... | 52 |
| Modifications | 53 |

BASIC OPERATION & RIDING 55

| | |
|---|----|
| Safe Riding Precautions | 57 |
| Off-road Use Only | 57 |
| Keep Hands and Feet on Controls..... | 58 |
| Control Speed..... | 59 |
| Use Care on Unfamiliar or Rough Terrain..... | 60 |
| Do Not Perform Stunts..... | 61 |
| Starting & Stopping the Engine | 62 |
| Preparation | 63 |
| Starting Procedure..... | 64 |
| Flooded Engine | 65 |
| Bank Angle Sensor Ignition Cut-off System | 65 |
| Stalled Engine | 66 |
| How to Stop the Engine | 67 |
| Shifting Gears | 68 |
| Riding in Reverse | 74 |
| Braking..... | 76 |
| Riding Your ATV | 78 |
| Making Turns | 78 |
| Skidding or Sliding | 80 |
| Riding Up Hills | 81 |
| Riding Down Hills | 85 |
| Crossing or Turning on Hills or Slopes..... | 86 |
| Riding Over Obstacles | 88 |
| Riding Through Water | 89 |