

T	
Throttle	
Cable	104
Lever.....	20, 104
Tires	
Inflation and air pressure	142
Repairing.....	145
Specifications	143
Tread condition	144
Tool kit	99
Trailer hitch	41
Trailer towing	
Operational guidelines.....	50
Weight limits.....	49
Transporting procedures.....	152
Tripmeter.....	28
Turning	
On level ground.....	78
On slopes	91
2WD/4WD select switch.....	26
V	
Valve clearance	121
W	
Warning labels	7
Warranty service.....	165
Water	
Draining from brakes	140
Riding through.....	93
Weight limits	49
Wheel removal.....	141
Wiring diagram	162