


Controls & Features

Engine Stop Switch



LEFT HANDLEBAR



(1) engine stop switch

○ RUN
⊗ OFF

The engine stop switch (1) is used to stop the engine in an emergency. To operate, press the switch to either OFF (⊗) position. The switch must be in the RUN (○) position to start the engine, and it should normally remain in the RUN (○) position even when the engine is OFF.