

Indicators & Controls

This section shows the location of all indicators and controls you would normally use before or while riding your ATV.

The items listed on this page are described in this section. Instructions for other components are presented in other sections of this manual where they will be most useful.

Operation Component Locations	10
Indicators.....	13
High Coolant Temperature Indicator	13
Neutral Indicator (TRX450ER only).....	14
Controls & Features	15
Fuel Valve	15
Choke Knob	16
Hot Start Lever (TRX450R only).....	17
Ignition Switch.....	18
Start Button (TRX450ER only).....	19
Kickstarter (TRX450R only).....	20
Engine Stop Switch.....	21
Headlight Switch.....	22
Headlight Dimmer Switch.....	22
Throttle Lever	23
Clutch Lever/Parking Brake Lever	23
Front Brake Lever	24
Rear Brake Pedal.....	24
Parking Brake.....	25
Flag Pole Bracket.....	26