
## **Vehicle Identification**

## **Serial Numbers**

The VIN and engine serial numbers and key number may be required when ordering replacement parts. Record the numbers here for your reference.

The VIN (1) is stamped on the front of the frame.


(1) VIN



The engine number (2) is stamped on the left side of the crankcase.

ENGINE No.

## **LEFT SIDE**



198 Technical Information