



# Instruments & Controls

- Controls & Features .....27
  - Fuel Valve .....27
  - Choke Knob .....28
  - Ignition Switch .....29
  - 2WD/4WD Select Switch .....30
  - Start Button .....31
  - Engine Stop Switch .....31
  - Headlight Switch .....32
  - Headlight Dimmer Switch .....32
  - Starting Primer Knob .....33
  - Recoil Starter .....33
  - Throttle Lever .....34
  - Gearshift Switch .....35
  - Reverse Selector Knob .....36
  - Front Brake Lever .....37
  - Rear Brake Lever .....37
  - Rear Brake Pedal .....37
  - Parking Brake .....38
  - Flag Pole Bracket .....39
  - Trailer Hitch .....40
  - Accessory Socket .....41
  - Utility Box .....43
  - Storage Compartment .....44
  - PS (Electric Power Steering) (TRX500FPE only) .....45

