


Controls & Features

Reverse Selector Knob

The reverse selector knob (1), located on the rear brake lever (2), is used to shift into reverse. To operate, with your ATV stopped and the transmission in neutral (make sure the neutral indicator lights), push in the knob, squeeze the rear brake lever, then depress the shift lever. See *Riding in Reverse*, page 60 .

LEFT HANDLEBAR



(1) reverse selector knob

(2) rear brake lever