

11. Air cleaner housing.

Check for deposits in the housing.

If necessary, clean the air cleaner, sub air cleaner and housing (pages 122 – 124).

