


# Operating Controls

## Choke Lever



LEFT SIDE



(1) choke lever

(A) fully ON  
(B) fully OFF

The choke lever may be used when starting the engine. See page 56 .