

# Index

## T

throttle,	
cable .....	110
lever.....	23
tires,	
air pressure .....	127
flat .....	167
replacing.....	132
repairing .....	131
thread conditions .....	130
tool kit .....	93
training, rider.....	32
transporting your ATV .....	154
trouble, unexpected .....	161
troubleshooting, starting.....	164
turning,	
on level ground.....	66
on hills or slopes.....	74

## V

valve, fuel.....	18
valve clearance .....	116