

# Maintenance Schedule

ITEMS	FREQUENCY	WHICHEVER COMES FIRST		INITIAL MAINT.	REGULAR MAINT. INTERVAL		Refer to page
		⇒	km	150	1000	2000	
			mi	100	600	1200	
		NOTE	HOURS	20	100	200	
DRIVE CHAIN		NOTE 1, NOTE 2		I, L	EVERY 500 km (300 mi) or 50 operating hours		134
DRIVE CHAIN SLIDER							136
* BRAKE SHOE WEAR		NOTE 1					123
BRAKE SYSTEM							119
SKID PLATES							133
* CLUTCH SYSTEM							111
* SUSPENSION							—
* SPARK ARRESTER					C	C	118
* NUTS, BOLTS, FASTENERS							—
** WHEELS/TYRES							—
** TIE-ROD AND JOINT BOOTS							—
** STEERING SHAFT HOLDER BEARINGS							—
** STEERING SYSTEM							—

- \* Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official Honda Shop Manual.
- \*\* In the interest of safety, we recommend these items be serviced only by your Honda dealer.