

Engine Idle Speed and Air-Fuel Mixture

Air-Fuel Mixture Adjustment

Air screw is available to compensate for air-fuel mixture. For those who are mechanically proficient and have the necessary tools, adjustment procedures are given in the official Honda Shop Manual available from your Honda dealer. All others should have this carburetor modification performed by a Honda dealer.