


Front and Rear Suspension Inspection

1. Check the front fork assembly by locking the front brake and pumping the fork up and down vigorously. Suspension action should be smooth and there must be no oil seepage.
2. Rear fork bushing—this can be checked by pushing hard against the side of the rear wheel while the motorcycle is on the center stand and feeling for looseness of the fork bushings.
3. Carefully inspect all front and rear suspension fasteners for tightness.

Side Stand

Check the rubber pad for deterioration or wear. Replace if any wear extends to wear line (1) as shown.



Inspection des suspensions avant et arrière

1. Vérifier l'ensemble de fourche avant en bloquant le frein avant et en pompant la fourche vers le haut et vers le bas vigoreusement. L'action de la suspension doit être sans à-coups et il ne faut pas exister aucune infiltration de l'huile.
2. Jeu du bras oscillant. Pour le vérifier pousser avec une force suffisante sur la roue arrière après avoir mis la moto sur la béquille centrale afin de constater un jeu éventuel au niveau de l'articulation.
3. Vérifier soigneusement l'état de serrage des visseries des suspensions avant et arrière.

Bequille latérale

Vérifier si le tampon en caoutchouc n'est pas détérioré ou usé. Le remplacer si l'usure dépasse la limite indiquée (1).