

FREQUENCY ITEM		WHICHEVER →	ODOMETER READING [NOTE(1)]								REFER TO PAGE	
			COMES FIRST ↓	x 1,000 km	1	6	12	18	24	30		36
		NOTE	x 1,000 mi	0.6	4	8	12	16	20	24		
	DRIVE CHAIN			I, L, EVERY 1,000 km (600 mi)								85-89
	DRIVE CHAIN SLIDER				I			I		I	90	
	BRAKE FLUID	(NOTE 3)			I	I	R	I	I	R	23-26	
	BRAKE PAD WEAR				I	I	I	I	I	I	101	
	BRAKE SYSTEM		I		I			I		I	23-26, 102	
*	BRAKE LIGHT SWITCH				I			I		I	108	
*	HEADLIGHT AIM				I			I		I	-	
	CLUTCH SYSTEM				I			I		I	27	
	CLUTCH FLUID	(NOTE 3)			I	I	R	I	I	R	27	
	SIDE STAND					I		I		I	102	
*	SUSPENSION					I		I		I	91	
*	NUTS, BOLTS, FASTENERS		I		I			I		I	-	
**	WHEELS/TYRES				I			I		I	-	
**	STEERING HEAD BEARINGS		I		I			I		I	-	