




Operation Guide










Odometer [TOTAL] & Tripmeter [TRIP A/B] & Mileage countdown

SEL button switches between the odometer, the tripmeter A, the tripmeter B and the mileage countdown.



Odometer

Total distance ridden. When "-----" is displayed, go to your dealer for service.

Tripmeter

Distance ridden since tripmeter was reset. When "-----" is displayed, go to your dealer for service

To reset the tripmeter: P.28

Mileage countdown

Distance travelled is subtracted from a preset figure.

Display range: 999.9 to 0.0 km or mile When the countdown value reaches "0.0" km or mile while riding, the number will flash

continued 23









