

ITEM	FREQUENCY	NOTE	ODOMETER READING [NOTE (1)]								Refer to page	
			x 1,000 km	1	6	12	18	24	30	36		
			x 1,000 mi	0.6	4	8	12	16	20	24		
			MONTH		6	12	18	24	30	36		
DRIVE CHAIN				EVERY 1,000 km (600 mi) I, L								67
DRIVE CHAIN SLIDER					I			I		I	73	
BRAKE FLUID	(NOTE 4)				I	I	R	I	I	R	13	
BRAKE SHOE/PAD WEAR					I	I	I	I	I	I	75, 76	
BRAKE SYSTEM				I		I		I		I	13	
* BRAKE LIGHT SWITCH						I		I		I	87	
* HEADLIGHT AIM						I		I		I	—	
CLUTCH SYSTEM				I	I	I	I	I	I	I	17	
SIDE STAND						I		I		I	74	
* SUSPENSION						I		I		I	—	
* NUTS, BOLTS, FASTENERS				I		I		I		I	—	
** WHEELS/TYRES						I		I		I	—	
** STEERING HEAD BEARINGS				I		I		I		I	—	