

INSTRUMENTS AND INDICATORS

The indicators are located within and near the speedometer.

Their functions are described in the table on the following page.

- (1) Speedometer
- (2) Odometer
- (3) Neutral indicator
- (4) Turn signal indicator
- (5) High beam indicator
- (6) Tripmeter
- (7) Coolant temperature indicator
- (8) Low oil pressure indicator
- (9) Tripmeter reset knob

