

MAINTENANCE

page

64 MAINTENANCE

- 64 THE IMPORTANCE OF MAINTENANCE
- 65 MAINTENANCE SAFETY
- 66 SAFETY PRECAUTIONS
- 67 MAINTENANCE SCHEDULE
- 70 TOOL KIT
- 71 SERIAL NUMBERS
- 72 COLOUR LABEL
- 73 ENGINE OIL
- 78 CRANKCASE BREATHER
- 79 SPARK PLUGS
- 81 FINAL DRIVE OIL
- 82 THROTTLE OPERATION
- 83 COOLANT
- 84 AIR CLEANER
- 85 FRONT AND REAR SUSPENSION INSPECTION
- 86 SIDE STAND
- 87 WHEEL REMOVAL
- 96 BRAKE PAD WEAR
- 97 BRAKE SHOE WEAR

page

- 98 BATTERY
- 101 FUSE REPLACEMENT
- 104 BRAKELIGHT SWITCH ADJUSTMENT
- 105 BULB REPLACEMENT
- 110 CLEANING**
- 113 STORAGE GUIDE**
 - 113 STORAGE
 - 115 REMOVAL FROM STORAGE
- 116 TAKING CARE OF THE UNEXPECTED**
- 117 SPECIFICATIONS**
- 122 CATALYTIC CONVERTERS**