

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								Refer to page
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		MONTH		6	12	18	24	30	36		
* FUEL LINE					I		I		I	—	
* THROTTLE OPERATION					I		I		I	82	
AIR CLEANER	NOTE (2)					R			R	84	
CRANKCASE BREATHER	NOTE (3)			C	C	C	C	C	C	78	
SPARK PLUGS				I	R	I	R	I	R	79	
* VALVE CLEARANCE				I		I		I	I	—	
ENGINE OIL				R		R		R	R	73	
ENGINE OIL FILTER				R		R		R	R	75	
* ENGINE IDLE SPEED				I	I	I	I	I	I	—	
RADIATOR COOLANT	NOTE (4)					I		I	R	28	
* COOLING SYSTEM						I		I	I	—	
* SECONDARY AIR SUPPLY SYSTEM						I		I	I	—	