

ITEM	FREQUENCY	WHICHEVER →	ODOMETER READING [NOTE (1)]								REFER TO PAGE	
			COMES	x 1,000 km	1	6	12	18	24	30		36
			FIRST ↓	x 1,000 mi	0.6	4	8	12	16	20		24
			NOTE	MONTH	6	12	18	24	30	36		
	DRIVE CHAIN			EVERY 1,000 km (600 mi) I, L								61
	BRAKE FLUID	(NOTE 4)			I	I	R	I	I	R	14	
	BRAKE SHOE/PAD WEAR				I	I	I	I	I	I	68, 69	
	BRAKE SYSTEM			I		I		I		I	14, 68, 69	
*	BRAKE LIGHT SWITCH					I		I		I	77	
*	HEADLIGHT AIM					I		I		I	—	
	CLUTCH SYSTEM			I	I	I	I	I	I	I	18	
	SIDE STAND					I		I		I	67	
*	SUSPENSION					I		I		I	—	
*	NUTS, BOLTS, FASTENERS			I		I		I		I	—	
**	WHEELS/TYRES			I	I	I	I	I	I	I	—	
**	STEERING HEAD BEARINGS			I		I		I		I	—	