

Index

L

labels, safety	7
lamp check	14
limit, weight	33
load limits	33
loading guidelines	33
lock, steering	47
low oil pressure indicator	13, 16, 168

M

maintenance,	
component locations	67
importance	54
periodic	58
record	65
safety	55
schedule	60
manual, service	202
maximum weight limit	33
modifications	6

N

neutral indicator	13, 16
numbers, serial	178