Taking Care of the Unexpected

This section discusses the more common problems that can occur with your motorcycle while you're riding. It tells you how to evaluate each problem and what actions you can take to try to resume riding. If the problem cannot be safely solved, this section also gives instructions on the proper way to have your motorcycle transported.

For information about transporting your motorcycle, see page 142.

General Guidelines	146
If Your Engine Quits or	
Won't Start	. 147
If You Have a Flat Tire	. 152
If Your Engine Overheats	. 162
If the Low Oil Pressure Indicator	
Lights	. 164
If a Fuse Blows	
If You Crash	. 169
If You Lose Your Key	. 170
If Your Battery is Low (or Dead)	