

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								Refer to page
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
			MONTH		6	12	18	24	30	36	
* FUEL LINE					I			I		I	—
* THROTTLE OPERATION					I			I		I	78
AIR CLEANER	NOTE (2)					R				R	80
CRANKCASE BREATHER	NOTE (3)			C	C	C	C	C	C	C	74
SPARK PLUGS				I	R	I	R	I	R	I	75
* VALVE CLEARANCE			I		I		I		I		—
ENGINE OIL			R		R		R		R		69
ENGINE OIL FILTER			R		R		R		R		71
RADIATOR COOLANT	NOTE (4)				I		I		R		24
* COOLING SYSTEM					I		I		I		—
* SECONDARY AIR SUPPLY SYSTEM					I		I		I		—