



Instruments & Controls

This section shows the location of all gauges, indicators, and controls you would normally use before or while riding your motorcycle.

The items listed on this page are described in this section. Instructions for other components are presented in other sections of this manual where they will be most useful.



Operation Component Locations	10
Gauges, Indicators & Displays.....	13
Multi-function Display.....	19
Coolant Temperature Meter.....	20
Speedometer	22
Odometer	22
Tripmeter	22
Changing the Speed Unit	23
Controls & Features	
Choke Knob.....	24
Ignition Switch	25
Start Button.....	26
Engine Stop Switch	26
Headlight Dimmer Switch	27
Turn Signal Switch.....	27
Horn Button.....	28
Multi-function Select and Reset Button	28

