



Table of Contents

BASIC OPERATION & RIDING 39	SERVICING YOUR HONDA 57
Safe Riding Precautions 40	<i>Before You Service Your Honda</i>
Starting & Stopping the Engine 41	The Importance of Maintenance 60
Preparation..... 41	Maintenance Safety 61
Starting Procedure 42	Important Safety Precautions 62
Flooded Engine..... 44	Periodic Maintenance 64
Bank Angle Sensor Ignition Cut-off	Maintenance Schedule 66
System..... 45	Maintenance Record..... 71
How to Stop the Engine 46	<i>Service Preparations</i>
Shifting Gears..... 47	Maintenance Component Locations 73
Braking 49	Tool Kit..... 76
Parking..... 51	Owner's Manual Storage..... 77
Riding with a Passenger or Cargo..... 55	Seat Removal 78
	Rear Cowl Removal 81
	Lower Fairing Removal 82
	Inner Fairing Removal 84
	Clip Removal 85
	Raising the Fuel Tank 86

