

Refuelling

Fuel type: Unleaded petrol only

Fuel octane number: Your scooter is designed to use Research Octane Number (RON) 91 or higher.

Tank capacity: 5.9 litres (1.56 US gal, 1.30 Imp gal)

Refuelling and Fuel Guidelines  **P.14**

Opening the Fuel Fill Cap

- 1 Insert the ignition key and turn it to the position of OPENER.
- 2 Push the FUEL side of the fuel lid and seat opener switch.
 - ▶ The fuel lid opens.

