

- Have your tyres replaced by your dealer. For recommended tyres, air pressure and minimum tread depth, see "Specifications." P. 107
- Follow these guidelines whenever you replace tyres.
- Use the recommended tyres or equivalents of the same size, construction, speed rating, and load range.
 - Have the wheel balanced with Honda Genuine balance weights or equivalent after the tyre is installed.
 - Do not install a tube inside a tubeless tyre on this scooter. Excessive heat build-up can cause the tube to burst.
 - Use only tubeless tyres on this scooter. The rims are designed for tubeless tyres, and during hard acceleration or braking, a tube-type tyre could slip on the rim and cause the tyre to rapidly deflate.

⚠ WARNING

Installing improper tyres on your scooter can adversely affect handling and stability, and can cause a crash in which you can be seriously hurt or killed.

Always use the size and type of tyres recommended in this owner's manual.