


## Position Light Bulb



1. Turn the socket counterclockwise and pull it out.
2. Pull out the bulb without turning it.
3. Install a new bulb and parts in the reverse order of removal.