



## OPERATING INSTRUCTIONS

### Speedometer/Tachometer

Speedometer and tachometer are mounted above the headlight case. Their respective functions are shown in the table on the next page.



- ① Speedometer
- ② Odometer
- ③ High beam indicator light
- ④ Neutral indicator light
- ⑤ Tachometer
- ⑥ Tachometer red zone
- ⑦ Tripmeter
- ⑧ Tripmeter reset knob