



For your Safety

Stop the engine and remove the ignition key when carrying out any maintenance works.



The motorcycle should be supported by the Side-Stand, on a flat and solid surface.