

Instruments

Turn Signal Switch:


The Turn Signal switch is used to operate the Turn Signal Lamps when turning Left or Right, or when changing lanes.

The Ignition Switch must be in the 'ON' position for the Turn Signal Lamps to operate.

To operate, push the switch button to the side that corresponds with the Turning direction. ie; R.....Right and L.....Left.

- TIP -

- The Turn Signals do not automatically cancel. Always cancel the Turn Signal after turning to avoid confusing other road users.
- Always use correct wattage globes - Use of incorrect wattage globes may result in erratic or incorrect flash rate.



Turn Signal Switch