

ITEMS	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	INITIAL MAINT.	REGULAR MAINT. INTERVAL					REFER TO PAGE
				km	1,000	2,000	3,000	4,000	
				mi	600	1,200	1,800	2,400	
	NOTE	MONTH	1	6	12	18	24		
	BRAKE FLUID	NOTE (2)			I	I	I	I	30, 31
	BRAKE PAD WEAR				I	I	I	I	95
	BRAKE SYSTEM		I	I	I	I	I	I	30 - 31
	BRAKE LIGHT SWITCH					I		I	104
*	HEADLIGHT AIM					I		I	-
	CLUTCH SYSTEM		I	I	I	I	I	I	32 - 33
	SIDE STAND					I		I	103
	SUSPENSION					I		I	100, 101
*	SPARK ARRESTER			Every 1,600 km (1,000 mi) or every 100 operating hours: C					88
*	NUTS, BOLTS, FASTENERS		I			I		I	-
**	WHEELS/TYRES		I	I	I	I	I	I	40, 102
**	STEERING HEAD BEARINGS		I			I		I	-