

MAINTENANCE SCHEDULE

Perform the Pre-ride Inspection (page 45) at each scheduled maintenance period.

I: INSPECT AND CLEAN, ADJUST, LUBRICATE OR REPLACE IF NECESSARY

C: CLEAN R: REPLACE A: ADJUST L: LUBRICATE

ITEMS	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	INITIAL MAINT.	REGULAR MAINT. INTERVAL					Refer to page	
				x100km	10	20	30	40		
				x100mi	1	6	12	18		24
				MONTH	1	6	12	18		24
* FUEL LINE					I		I	—		
** FUEL STRAINER SCREEN					C		C	—		
* THROTTLE OPERATION					I		I	73-74		
AIR CLEANER	NOTE1			C	C	C	C	63-64		
SPARK PLUG				I	I	I	I	70-71		
* VALVE CLEARANCE			I	I	I	I	I	—		
ENGINE OIL			R	R	R	R	R	65-69		
ENGINE OIL FILTER			R	R	R	R	R	68-69		
* ENGINE OIL STRAINER SCREEN IN DOWN TUBE					C		C	—		
* DECOMPRESSOR SYSTEM			I	I	I	I	I	49		
** ENGINE IDLE SPEED			I	I	I	I	I	72		
DRIVE CHAIN	NOTE1		I,L	Every 500km(300mi) or every 3 month:I,L				76		
DRIVE CHAIN SLIDER				I	I	I	I	77		