

Quick Reference

Break-in Maintenance	first week of operation, about 200 miles (350 km)
Regular Maintenance	every 30 riding days, about 1,000 miles (1,600 km)
Pre-ride Inspection	Check the following items each time before you ride (page 25): tires, rims, leaks, engine oil, fuel, drive chain, cables, nuts & bolts, throttle, and brakes.
Fuel/Capacity	unleaded gasoline, pump octane number of 86 or higher tank: 6.2 ℓ (1.64 US gal , 1.36 Imp gal) reserve: 2.1 ℓ (0.55 US gal , 0.46 Imp gal)
Engine Oil	API Service Classification SF or SG; SAE 10W-40
Maximum Weight Capacity	60 kg (132 lbs) rider only (no passenger or cargo) and any accessories
Tires	Front: 2.50-14 4PR , Rear: 3.00-12 4PR
Tire Pressure (cold)	Front: 100 kPa (1.00 kgf/cm ² , 15 psi) Rear: 100 kPa (1.00 kgf/cm ² , 15 psi)
Spark Plug	CR6HSA (NGK) or U20FSR-U (NIPPONDENSO)