

Is Your Motorcycle Ready to Ride ?

Spark Plug & Cap Check for looseness (page 75).

Check these items **after** you get on the motorcycle:

Throttle Check the freeplay and adjust if needed. Rotate the throttle to make sure it moves smoothly without sticking, and snaps shut automatically when it is released, in all steering positions (page 66).

Brakes Squeeze the front brake lever and step on the rear brake pedal to check that the controls operate normally (page 81). Adjust freeplay, if necessary. (pages 81 , 83).

Clutch Lever Check for smooth operation and adjust if needed (page 68).

Remember, be sure to take care of any problem you find or have your Honda dealer correct it before you ride.