

Loading

The combined weight of the rider, luggage and additional accessories must not exceed 158 kg (348 lbs), Zul Ges Gewicht. Luggage weight alone should not exceed 18 kg (39 lbs).

1. Keep luggage and accessory weight low and close to the center of the motorcycle. Load weight equally on both sides to minimize imbalance. As weight is located farther from the motorcycle's center of gravity, handling is proportionally affected.
2. Adjust tire pressure (Tire Servicing, page 106).

Carga

El peso combinado del conductor, de la carga y de los accesorios adicionales no tiene que exceder de 158 kg (348 lbs), Zul Ges Gewicht. El peso de la carga por sí sola no deberá exceder de 18 kg (39 lbs).

1. Mantener el peso de la carga y de los accesorios bajo y cerca del centro de la motocicleta. El peso de carga por igual en ambos lados para reducir desequilibrios. A medida que el peso de coloca apartado del centro de gravedad de la motocicleta, la conducción queda proporcionalmente afectada.
2. Ajustar la presión de los neumáticos (Mantenimiento de las llantas, página 106).