



- (1) MAIN WIRE HARNESS (TO CONNECTOR COVER)
- (2) MAIN WIRE HARNESS (TO RELAY)
- (3) MAIN WIRE HARNESS (TO ECU)
- (4) CRANKCASE BREATHER JOINT HOSE
- (5) TRANSMISSION BREATHER HOSE
- (6) WIRE HARNESS
- (7) FUEL RETURN HOSE
- (8) FUEL FEED HOSE

- (9) REGULATOR/RECTIFIER 5P (BLACK) CONNECTOR
- (10) CONDENSOR
- (11) CONDENSOR 2P (BLACK) CONNECTOR
- (12) BANK ANGLE SENSOR
- (13) FAN MOTOR RELAY
- (14) CONNECTOR COVER
- (15) SPEED SENSOR CABLE