


LUBRICATION POINTS

Use general purpose grease when no other specification is given. Apply oil or grease to any 2 sliding surfaces.



SPECIAL LUBRICANT

- SHOCK ABSORBER UPPER MOUNT COLLAR (Page 12-11)
- SUSPENSION LINKAGE PIVOTS (Page 2-13)