



## HANDLEBAR

### REMOVAL

Remove the throttle housing and front brake master cylinder from the handlebar.



Remove the clutch/parking brake lever bracket and switch housing from the handlebar.  
Remove the switch wire bands.



Remove the handlebar upper holders and the handlebar.

