


Switches (Continued)

Steering Lock

Lock the steering when parking to help prevent theft.
A U-shaped wheel lock or similar device is also recommended.



Locking

- 1 Turn the handlebar all the way to the left.
- 2 Push the ignition switch down, and turn it to the **L** (Lock) position.
 - ▶ To unlock the ignition switch. **▶P.34**
 - ▶ Jiggle the handlebar if the lock is difficult to engage.
- 3 Lock the ignition switch. **▶P.35**

Unlocking

- Push the ignition switch in, and turn it to the OFF position.
- ▶ To unlock the ignition switch. **▶P.34**