

Instruments, Controls, & Other Features

Ignition Switch

Leaving the ignition switch in the ON position with the engine stopped will drain the battery. Do not turn the ignition switch while riding.

Engine Stop Switch

Do not use the engine stop switch except in an emergency. Doing so when riding will cause the engine to suddenly turn off, making riding unsafe.

If you stop the engine using the engine stop switch, turn the ignition switch to the OFF position. Failing to do so will drain the battery.

Odometer

The display locks at 999,999 when the read-out exceeds 999,999.

Tripmeter

The tripmeters return to 0.0 when each read-out exceeds 9,999.9.

Document Bag

The owner's manual, registration, and insurance information can be stored in the plastic document bag behind the right side cover.

High Beam Indicator

The high beam indicator will come on briefly due to the LED light capacitor being discharged when the ignition switch is turned to the ON position immediately after the engine was stopped while the high beam was on.

Headlight

The headlight will come on briefly due to the LED light capacitor being discharged when the headlight dimmer switch is operated immediately after the engine was stopped while the high beam was on.