


Ignition switch

Switches the electrical system on/off and locks the steering.

To unlock the ignition switch: ➔ P.34



Lock

Locks steering.

OFF

Turns engine off.

ON

Turns electrical system on for starting/riding.



Answer back button

This button is used to operate the answer back system.

Answer Back System: ➔ P.42

Alarm button

This button is used to operate the anti-theft alarm system.

Anti-theft Alarm System:

➔ P.37

ON/OFF button

This button is used to activate or deactivate the Honda SMART Key system, and also to confirm the activation status. ➔ P.30