


■ Cancelling the Anti-theft Alarm System

- 1 To cancel the anti-theft alarm system, do one of the following:
 - Press the alarm button on the Honda SMART Key.
 - Unlock the ignition switch. ➡ P.34
 - Press the seat open button while the Honda SMART Key is in the operating range. ➡ P.31
- 2 Make sure that the turn signal light and alarm indicator blink 2 times, and the buzzer rings 2 times. This indicates that the anti-theft alarm system is cancelled.

Alarm button



■ Stopping the Anti-theft Alarm Activation

To stop the anti-theft alarm activation, do one of the following:

- Press the alarm button on the Honda SMART Key.
- Press the answer back button on the Honda SMART Key.
- Unlock the ignition switch. ➡ P.34
- Press the seat open button. ➡ P.52

After stopping the anti-theft alarm activation, the anti-theft alarm system will be cancelled.

Alarm button

Answer back button

